




TOP AND CONSOLE PARTS

For Model: LER3624JQ0
(Designer White)

29" ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: LER3624JQ0

(Designer White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	LIT8314844	Literature Parts Use And Care Guide	4	8271365	Cap, End (L.H.)	16	8271390	Top
	LIT3397618	Installation Instructions	5	3936144	Connector	17	297535	Bumper, Lint Lid
	LIT3406688	Wiring Diagram	6	388326	Screw, Console	18	3394427	Clip, Harness
			7	3400859	Screw, Grounding	19	3401076	Resistor Assembly
			8	8271359	Cap, End (R.H.)	21	3976575	Timer, 60 Hz.
			9	8274261	Panel, Rear Console	22	357213	Nut, Push-In (2)
		Following May Be Purchased	10	339392	Screen, Lint	23	3394292	Harness, Wiring
		DO-IT-YOURSELF REPAIR MANUALS	11	8283378	Cover, Lint Screen	24	3395382	Switch, Push-To-Start
			12	3978605	Hinge, R.H. 3978606 Hinge, L.H.	25	8312687	Timer Knob Assembly
			13	688983	Screw, 8-18 x 5/8	26	8271418	Bracket, Control
2	693995	Screw, Hex Head	14	94614	Terminal	27	3977813	Panel, Control
3	3390646	Screw, 8-18 x 5/16	15	3395683	Connector (Motor)	28	8271341	Knob, Push To Start


LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
		PAINT, TOUCH-UP (1/2oz.)			PAINT, PRESSURIZED SPRAY (12 oz.)			PAINT, BULK (1 qt.)
		72017 White			350930 White 350938 Primer, Gray			799344 White (Uncut)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: LER3624JQ0
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: LER3624JQ0

(Designer White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2	3393008	Screw, 10-16 x 1/2	15	693197	Front Panel Assembly	26	3397659	Block, Terminal
4	343641	Screw, 10-16 x 1/2	16	685203	Clip, Felt Pad	27	238088	Hinge, Top (2)
5	3396795	Cover, Terminal Block	17	3389441	Catch, Door	28	3394332	Idler & Pulley Assembly
6	3396807	Panel, Rear	18	348023	Hinge and Pin Assembly (2)	29	8066065	Belt, Drive
7	694091	Screw, 8-18 x 3/8	19	3394083	Clip, Front Panel (2)	30	348780	Base, Motor
8	3406102	Door Switch Assembly	20	696144	Strike, Door	31	3400500	Bolt, 5/16-18 x 3/4
9	697773	Screw, 6-20 x 7/8	21	695656	Door, Rear	32	3394341	Pulley, 60 Hz.
10	693995	Screw, Hex Washer Head	22	348205	Door Front	33	3976707	Motor Assembly 60 Hz.
11	3392100	Foot, Dryer (4)	23	686711	Handle, Door	34	660658	Clamp, Motor
12	3399580	Cabinet Assembly (Includes Illus. Nos. 5, 7, 16, 29, 41 & 57)	24	349462	Seal & Bearing Assembly	35	3404162	Clamp, Motor (W/Shield)
13	98234	Clip, Ground	25	279393	Terminal Block Kit For Terminal Block	36	3390734	Seal, Door
14	690363	Lock, Front Top (2)				37	697776	Screw, 10-32 x 1/2 (External Ground)
						38	279318	Terminal, Tinned & Brass (3) (Includes Illus. 40)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: LER3624JQ0

(Designer White)

